

MAINTENANCE

WH2000i Series Service Parts



Figure 55

MAINTENANCE

| Item | WPP# | Description | Qty |
|------|--------|--|-----|
| 1 | 260027 | Indicator Lights | 1 |
| 2 | 260005 | Reset Breaker | 1 |
| 3 | 260014 | Efficiency Mode Switch | 1 |
| 4 | 260021 | Choke Cable | 1 |
| 5 | 260039 | 12-volt DC Power Socket – WH2000iXLT Model | 1 |
| 6 | 260020 | Recoil Starter | 1 |
| 7 | 260019 | Spark Plug Cover | 1 |
| 8 | 260003 | A5RTC (Torch) Spark Plug | 1 |
| 9 | 260017 | Oil Filling Cover | 1 |
| 10 | 260015 | Oil Filler Plug | 1 |
| 11 | 260018 | Draining Fuel Cover, Carburetor | 1 |
| 12 | 260026 | Rubber Support Feet | 4 |
| 13 | 260016 | Air Cleaner Element | 1 |
| 14 | 260007 | Fuel Tank Cap Assy. | 1 |
| 15 | 260028 | Fuel Strainer | 1 |
| 16 | 260025 | Muffler Outer Cover | 1 |
| 17 | 260024 | Hose Clamp | 1 |
| 18 | 260023 | Lock Cap, Spark Arrestor Element | 1 |
| 19 | 260022 | Spark Arrestor Element | 1 |
| 20 | 260040 | Air Intake Cover | 1 |
| 21 | 260043 | Fuel Valve | 1 |
| 22 | 260044 | Engine/Fuel Control Knob | 1 |
| 23 | 140083 | Carburetor | 1 |
| 24 | 260048 | Front Housing – WH2000i Model | 1 |
| 25 | 260051 | Front Housing – WH2000iXLT Model | 1 |
| 26 | 260052 | Rear Housing | 1 |